


Quick guide for PCx/PCxop

81300052C



Information about the system

There are two access levels to the system

- Operator level: Access to change set-point values
- System level: Access to the whole system

With no access code can parameters only be viewed

The access codes default settings are:

- Operator code: 1
- System code: 2

Below it is shown how to put in an access code, acknowledge an alarm and to set a start/stop level.

Operator/system access

Press on  Type the **CODE** for operator or system access.





Press  to confirm. Now should it be displayed "**Choose function**" and the access level.

Acknowledge Alarm


The operator panel has 2 alarm diods, A - och B -alarm. When an alarm is not acknowledged they will be flashing, to acknowledge an alarm do as follows



Press on , the marker will now flash at "**Status**", Press .

Now the cursor is flashing on "**Not ackn.alarms**" and confirm the choice with .

Browse with  and  to the **Alarm** that shall be acknowledged and press .

To go back to the main menu or step back, press  a couple if times.

If the alarm led is lit is the alarm acknowledged but is still active and when the alarm goes off it will turn off automatically

Program Start/Stop for pump




Press on  type the access **code** and press  The OPI now displays "**Choose function**"

Press on  Move the cursor with  or  until the cursor is on "**Pump settings**"

Press on  to confirm the choice. Select "**Control**" and press  to confirm.

The cursor is now flashing on the choice "**Normal control**", press  to confirm.

Select the pump **1-16** confirm with . Press  until the cursor is flashing on the selected

parameter to change. **Type** the new value with the keypad and confirm with .

In general, it is with the white keys (arrows and numbers) that are used for putting in and change values and after that confirm with the ENTER key. This is also the way when manouver the menu tree To go back to the main menu or cancel an input the PROG/CANCEL key is used.

Information about the **Yellow** keys

The yellow keys shows the most common status and settings. Shall any settings be able to change must first the proper access code be inputted through the PROG/CANCEL-key see other side for guide

PUMP PIT **Status pumped vol.** Shows the pumped volume for the pump pit for the last 7 days and the total amount.



Settings

Shows the parameters with connection to the pump pit, ex. Areas for flow calculations, alarm levels, and general pump delays

Pump pit valve

Shows the settings for the valve of the pump pit

PUMP



Pump status

Shows the time of operation for the pumps, start counter and the capacity of the pump divided on the last seven days and the total capacity

Pump settings

Shows the parameters for the pump

Pump valve

Shows the settings for the valve that is working with the pump

Alarm blocking

Shows alarms that are connected to the pumps.

ALARM



Status

Shows the alarm list.

Configure

Shows the alarm types in groups or in order. There is a possibility to set a personal code for acknowledgement of alarms.

Set alarm

Shows only the alarms that are in operation in number order.

FLOW / PULSE



Accumulated flow

Shows the day flow for the last seven days and the total flow

Overflow status

Shows the overflow the last seven days and the total amount

Actual values

Shows the actual values on flow meters, pulse channels and overflow

Channel flow config

Shows and is used for configure the flow meters of channels and overflow meters.

PUMP START

Pump start



Is used to start and stop pumps manually via the PCx. The set levels of start and stop of the pump is in use. That means that a manually started pump with this function can be left on and the PCx control will stop the pump at its set stop level.

PARAMETERS

User specific param.

Shows user specific parameters that are configured through F6.



FUNCTION

Function codes



Shows more settings and information about the system. Below are some useful codes listed.

Function codes

Here are some of the most useful codes listed

F100 Time/Date

F110 Timer

F112 Sequence control with timer

F116 Power supply status and alarm

F120 LED setup for OPI

F124-128 Reset of status

F400 Analog logging settings

F401 Start register for exp. logging data

F405 Digital logging settings

F410 Analog logging

F415 Digital and alarm list

F600-660 Settings of speed control

F700-701 Settling pit

F702 Auto alternation on pump error

F703 Pump alternation option

F705 Min time of pump status change

F706 Settings for blocked pump

F707 Settings for check run of pump

F708 Pump control on level derivata

F710 Max no. of pumps run.simultaneously

F711 Max no. of pump. run.sim. in 2 pits

F720 Shift motor

F800-802 Communication parameters

F804-806 Cross reference settings

F807 Scaling of data registers

F810-813 Modem settings

F814-825 Alarm dial-up settings

F819 Station identity

F826 GSM PIN and PUK code

F827 GSM signal

F828 Block new alarms when visiting

F830-833 Master/slave settings

F840 IO-controlled data register

F950 Access codes

F900-902 Version information

Standard configurations

F872-873 Speed controlled pits

F882-883 Speed cont. booster stations.

F890 Simple 2-pump station

F892-894 Standard 2-4 pump stations

F899 Delivering initiation