


## Level Sensor XJ, XJC, XJS



(SV) Monterings- och installationsinstruktion

(EN) Assembly and installation instruction

(DE) Montageanleitung

(FR) Instructions de montage et d'installation

(IT) Istruzioni di montaggio e installazione

(ES) Instrucciones de instalación y montaje

(PT) Instruções de montagem e instalação

(ET) Koostamise ja paigalduse instruksioon

(DA) Montage- og installationsvejledning

(FI) Asennusohjeet

(EL) Οδηγίες εγκατάστασης και συναρμολόγησης

(NL) Montage- en installatie instructies

(NO) Montering- og installasjonsinstruksjon

(BG) Инструкция за монтаж

(CS) Návod na montáž a instalaci

(HR) Uputa za montažu i instalaciju

(HU) Összeállítási és szerelési útmutató

(LT) Surinkimo ir pastatymo instrukcija

(LV) Montāžas un uzstādīšanas instrukcija

(PL) Instrukcja instalacji i montażu

(RO) Instrucțiuni de asamblare și instalare






(SI) Navodila za montažo


(SK) Návod na montáž a inštaláciu

(TR) Montaj ve kurulum talimatları

(RU) Руководство по монтажу

(ZH) 装配及安装说明


XJ 25 - XJ 40	XJ 50 - XJ 80 - XJ 110	XJC 50 - XJC 80 - XJC 110
<p data-bbox="284 322 384 344">00863196</p> 	<p data-bbox="671 322 772 344">00863198</p> 	<p data-bbox="1050 322 1150 344">00863499</p> 
<p data-bbox="245 974 424 996">XJS 25 - XJS 80</p>	<p data-bbox="667 974 762 996">XJS 110</p>	
<p data-bbox="288 1052 389 1075">00863197</p> 	<p data-bbox="639 1052 804 1075">310 100 079 002</p> 	




6 mm	8 mm
XJ 25 - XJ 80 XJC 50 - XJC 80 XJS 25 - XJS 40	XJS 50 - XJS 110

**1**


**(XJ)**



**(XJC)**





**(XJS)**




**2**

**(XJ)**


**a →**



**b →**




**c**




**2**  
**(XJS)**


**a** →






**b**




**(XJC)**




**3**



**4**




**5**




**6**


**(XJ)**




**(XJS)**



**(XJC)**





**SULZER**

Sulzer Pump Solutions Ireland Ltd., Clonard Road, Wexford, Ireland  
Tel. +353 53 91 63 200, Fax +353 53 91 42 335, [www.sulzer.com](http://www.sulzer.com)