

Temperature and leakage relay type ABS CA 462





Installation guide

www.sulzer.com

Temperature and leakage relay type ABS CA 462

1 TECHNICAL DATA

1.1 Technical data CA 462

Temperature input threshold (±10	~ %)	> 3.3 kohm (PTC / Klixon)		
	70)			
Max PTC current		< 0.6 mA		
PTC source voltage		12 VDC		
Leakage sensor voltage		12 VDC		
Max leakage sensor current		< 15 µA		
Leakage detection threshold (±10%)		< 100 kohm		
Leakage alarm delay		10 seconds		
Ambient operating temperature		-20 to +50 °C (-4 to +122 °F)		
Ambient storage temperature		-30 to +80 °C (-22 to +176 °F)		
Degree of protection		IP20, NEMA: Type1		
Housing material		PPO and PC		
Mounting		DIN Rail 35 mm		
Installation category		CAT II		
Pollution degree		2		
Flame rate		V0 (E45329)		
Humidity		0–95% RH non-condensing		
Dimensions		H x W x D: 108 x 70 x 58 mm (4.25 x 2.76 x 2.28 inch)		
Dowor oupply	16907006	110-230 VAC, 50 Hz/60 Hz		
Power supply	16907007	18-36 VDC SELV or Class 2		
Fuse		Max 10 A		
Terminal wire size		Use copper (Cu) wire only. 0.2 - 2.5 mm ² flexible core, stripped length 8 mm.		
Terminal tightening torque		0.56 - 0.79 Nm (5 -7 lbs-in)		
Power consumption		< 5 W		
Max load alarm relays		250 VAC 3 Ampere resistive load		
Altitude		Max 2000 MASL or 6562 ft. AMSL		
Max load output pump blocking relay		250 VAC 6 Ampere resistive load		
Compliance				

Attention If the unit is used in a manner not described in this document the protection provided by the equipment may be impaired.

en

2 FUNCTION AND USAGE

CA 462 is a combined standalone leakage detection and temperature blocking relay for DIN rail mount.

2.1 Function leakage

In case of water leakage, the resistance between the sensor electrode and housing will decrease. If the resistance becomes less than 100 kohm (\pm 10 %) between terminals 11 and 12, the relay contact on terminal 1 and 2 closes. The signal has to be stable for at least 10 seconds before the relay is been activated.

2.2 Function temperature blocking

If the temperature in the pump is rising and the terminal protector sets off, the CA 462 is blocking the pump without any delay.

Automatic reset

- if terminal 14 and 15 are open; pump starts automatically when the temperature is back to normal.

Manual reset

 - if terminal 14 and 15 are bridged; manual reset has to be done by terminal 13 and 14 after the temperature is back to normal.

Terminal	Description
1	Leakage alarm relay (NO)
2	Leakage alarm relay
3	High temperature alarm relay (NO)
4	High temperature alarm relay
5	Pump relay (NO) (Closed under normal operation)
6	Pump relay
7	Power supply (0 V or N)
8	Power supply (+24 VDC or L1)
9	Input from pump temperature sensor (PTC / Klixon)
10	Input from pump temperature sensor (PTC / Klixon)
11	Input from pump leakage probes
12	Connect to ground or pump chassis
13	Reset switch for high temperature alarm
14	Reset switch for high temperature alarm
15	Manual reset required if bridged to terminal 14*

Table 1: Connection chart

* If bridged to terminal 14; manually reset is required after high temperature alarm *after* condition is back to normal. If **not** bridge; pump start automatically when condition is back to normal.

Table 2: Product reference

Article	Description
16907006	CA 462 110-230 VAC supply voltage
16907007	CA 462 18-36 VDC supply voltage

One item of Xylem MiniCas adapter is included in both 16907006 and 16907007.

Alarm type	Alarm LED		Input state		Output relay state			Remark
	Tempera- ture	Leakage	Temp (9 & 10)	Leak (11 & 12)	Pump (5 & 6)	Alarm (4 & 3)	Leak (2 & 1)	
			closed	open	closed	open	open	Normal operation
Temperature	Yes	-	> 3.3 kohm	open	open	closed	open	Pump stops
Leakage	-	Yes	closed	< 100 kohm	closed	open	closed	Pump runs
Temp. + leak.	Yes	Yes	> 3.3 kohm	< 100 kohm	open	closed	closed	Pump stops

Table 3: Logic table of relay

3 Dimensions

en



4

4 CONNECTION DIAGRAM

4.1 Electrical connection

If several sensors are to be used from the pump, then they must be connected together.

Leakage: Sensors must be in parallel.

It is very important to have in mind that this practice avoids alarms to be distinguished. Sulzer highly recommends to use one module per signal to allow not only distinguishing but also acting in a different way according to the alarm category/severity.

Temperature (Klixon or PTC): Sensors must be in series.



Figure 1 Electrical connection diagram

When several CA 462 units are used, the reset buttons cannot be wired together. The solution is to use one reset button to each unit or an external relay which control all the reset buttons as figure 2.





If pump is operated from a motor drive or frequency converter, special precautions are required.

The high electric noise level can distort electrical readings and in extension jeopardize functionality. To avoid conducted electrical noise, follow best practices and manufacturer EMC compliance recommendations when installing frequency converters. Use shielded cables and 50 cm separation between power and signal cables. Ensure that the cables are also separated from each other in cabinets.



5 ACCESSORIES

5.1 Xylem MiniCAS adapter

Xylem MiniCAS adapter is included in P/N **16907006** and **16907007**. The MiniCAS adapter can also be ordered as a spare part, P/N **16907009**.

5.1.1 Connection diagram MiniCAS adapter

Xylem MiniCAS adapter is a PCB with resistor network for interfacing CA 462 to Xylem MiniCAS relay. The output to MiniCas is polarity independent.



Figure 3 Connection diagram for MiniCAS adapter

Temperature input	Seal leak input	Output resistance	
ОК	ОК	Nominal (1500 Ω)	
ОК	Seal failure condition	LOW (400 Ω)	
Over-temperature condition (open or disconnected)	OK or seal failure condition	HIGH (>4000 Ω)	

6 CLEANING

en

How to clean the unit

Powers off the unit and only outside/front shall be cleaned by using a dry, soft cloth. A good choice would be the microfiber type of cloth and gently wipe the CA 462 unit on front in order not to scratch the overlay. If the dry cloth did not completely remove the dirt, do not press harder in an attempt to scrub it off. If necessary, moisten the cloth by adding a small amount of water with thin solution of mild detergent and try again. Never use detergent with polish or solvent which can have an impact of the plastic surface.

Copyright © 2023 Sulzer. All rights reserved.

This manual, as well as the software described in it, is furnished under license and may be used or copied only in accordance with the terms of such license. The content of this manual is furnished for informational use only, is subject to change without notice, and should not be construed as a commitment by Sulzer. Sulzer assumes no responsibility or liability for any errors or inaccuracies that may appear in this book.

Except as permitted by such license, no part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, recording, or otherwise, without the prior written permission of Sulzer.

Sulzer reserves the right to alter specifications due to technical developments.





Sulzer Pump Solutions Ireland Ltd., Clonard Road, Wexford, Ireland Tel. +353 53 91 63 200, www.sulzer.com